


Figure 1






Figure 3




Figure 4




Figure 5




Figure 6




Figure 7A





Figure 7B






Figure 9

<u>1000</u>

MVXL	Count	Destination	Source
------	-------	-------------	--------

Figure 10

- 1101. User calls Device Driver
 - Supplies

Source Network ID

Source Offset

Destination Network ID

- 1102. Device driver transfers addresses to Adapter
- 1103. Adapter Translates Addresses
 - Looks up Phyical Base addresses from ID's (Table Lookup)
 - Obtains Lock and current Destination Offset
 - Adds offsets
 - Checks bounds
- 1104. Adapter loads count and addresses in registers
- 1105. Adapter executes Data Move
- 1106. Adapter Frees Lock
- 1107. Adapter notifies device Driver which "Returns" to user

Figure 11

1201. User calls Device Driver

- Supplies

Source Network ID

Source Offset

Destination Network ID

1202. Device driver sends addresses to adapter

1203. Adapter Translates

- Looks up Phyical Base addresses from ID's (Table Lookup)
- Obtains Lock and current Destination Offset*
- Adds offsets
- Checks bounds
- Returns Lock and Physical addresses to Device Driver

1204. Device Driver executes Data Move

1205. Device Driver Frees Lock

1206. Device Driver Returns

Figure 12




Figure 13




Figure 14

